





30-40 Machine installation manual









M5螺母

M5 nut

铝材连接件

Aluminum
connecting
parts

尼龙传动轮

Nylon drive
wheel

亚克力
支架板

Acrylic
bracket sheet

2040

铝材

Aluminum

2020
铝材




安装铝型材连接件


Install aluminum profile
connections




上圖為2020鋁材安裝好鋁材連接件

2020 aluminum
profiles, installation
of good connections









Install the 2040
aluminum material on
that side


安装另一边2040铝材

Fit two M5 nuts, install control panel, acrylic











Fit the Y shaft on both sides of the synchronous belt



Push the M5 nut
into the belt by
hand


用手推入m5螺母固定皮带






用内六角扳手一头把m5螺母向里推

Push the nut to the
inside with an inner
six point wrench







Five nylon wheels
mounted on the Y shaft

Y轴亚克力板上安装5个尼龙传动轮



Black M5*30 inner
six corner screw

黑色M5*30内六角螺丝

M5*10尼龙柱

M10 nylon
column

